


**LT-72 TRANSFORMER** **INSTALLATION INSTRUCTIONS**

1. Use two wire nuts to attach the appropriate wires to the field wiring.
2. Cut off the exposed bare portion of the unused leads.



70 VOLT HOOK-UP	
Black	Common
White	0.5 Watt
Yellow	1 Watt
Blue	2 Watt
Brown	4 Watts
Varnished Wire	Speaker Terminals

25 VOLT HOOK-UP	
Black	Common
Brown	0.5 Watt
Green	1 Watt
Violet	2 Watt
Orange	4 Watts
Varnished Wire	Speaker Terminals

Specifications are subject to change without notice

[www.AtlasSound.com](http://www.AtlasSound.com)

1601 JACK MCKAY BOULEVARD ENNIS, TEXAS U.S.A. • TELEPHONE: (800) 876-3332 • FAX: (800) 765-3435

©2001 ATLAS SOUND LP

Printed in U.S.A.


00801

ATS000745 RevB 8/01

PN 461201

**LT-72 TRANSFORMER** **INSTALLATION INSTRUCTIONS**

1. Use two wire nuts to attach the appropriate wires to the field wiring.
2. Cut off the exposed bare portion of the unused leads.



70 VOLT HOOK-UP	
Black	Common
White	0.5 Watt
Yellow	1 Watt
Blue	2 Watt
Brown	4 Watts
Varnished Wire	Speaker Terminals

25 VOLT HOOK-UP	
Black	Common
Brown	0.5 Watt
Green	1 Watt
Violet	2 Watt
Orange	4 Watts
Varnished Wire	Speaker Terminals

Specifications are subject to change without notice

[www.AtlasSound.com](http://www.AtlasSound.com)

1601 JACK MCKAY BOULEVARD ENNIS, TEXAS U.S.A. • TELEPHONE: (800) 876-3332 • FAX: (800) 765-3435

©2001 ATLAS SOUND LP

Printed in U.S.A.

00801

ATS000745 RevB 8/01

PN 461201